BLAUPUNKT

CAR MULTIMEDIA

B910AU - SAN ANDREAS 970
powered by CVTE

Enjoy it.

Operating instructions

NOTE: Please do not watch videos or use other Apps while the vehicle is in motion.
Doing so, is a safety violation. To watch videos or use Apps, please ensure that the vehicle is in parked mode with handbrake activated.
Please check compatibility of the device with your mobile phone before purchase.
New phone software versions in the future may or may not be compatible with the device.
In-Warranty replacement will not be applicable for non compatibility of the mobile phone with the device.

1. Standby
2. Access Voice Command
3. Return to Home page
4. Increase volume
5. Decrease volume
6. Mute OFF / ON

Contents

Safety notes

The car audio system is manufactured according to recommended and established safety guidelines in a state of the art facility. Even so, dangers may occur if you do not observe the safety notes in the instruction manual.

These instructions are intended to familiarise you with important functions.
- For best results, please read the user manual carefully and completely before using the car audio system.
- Always keep the user manual accessible to all users.
- Always handover the car audio system to any third party along with these instructions
- In addition, observe the instructions of the devices used in combination with this car audio system

Symbols used

Below are the symbols used in this user manual, please go through them carefully:

CAUTION:
Warns about possibilities of any injuries that might occur.

DANGER:
Warns about damages to the DVD/CD drive (Not applicable to all Series 900 Model)

LOUD VOLUME:
Warns about high volume

- ✓ Identifies a sequencing step
- Identifies a listing

General Warning

To avoid any injury or damage to yourself, your car and others, please make sure to do as following. Observe the following note to protect yourself against injuries:

- **Do not modify or open the device.** Do not do any unauthorised modification to the device. In case you need any assistance, please visit the nearest service centre. The device should be open by an authorised person only.

- **Use as Directed:** this car audio system is intended for installation and operation in a vehicle with 12V (negative ground) vehicle system voltage. Observe the output limits of the device. Only an authorised specialist should perform repairs and installation, if necessary.

- **Installation Instructions:** You may only install the car audio system yourself if you are experienced in installing car audios systems, and are very familiar

with the electrical system of the vehicle. For this purpose, observe the connection diagram at the end of these instructions. For self-installation make sure you have the right tools with you.

- **Use your device in such a way that you can always safely control your vehicle.** In case of doubt, stop at a suitable location and operate your device while the vehicle is parked. As the driver, you must not use the applications that will distract you from traffic (depending on the scope of functions of the device, e.g. viewing videos, searching for a destination) (Navigation equipped radios and other downloaded application)

- **Follow driving recommendations during the route guidance only if you are not violating any traffic regulations:** Traffic signs and traffic regulations always have priority over driving recommendations.

- **Always listen** at moderate volume to protect your hearing and to be able to hear warning signals (e.g. police sirens and other external alerts while driving). During mute phases (e.g. when changing the audio source), changing the volume is not advisable. Do not increase the volume during this mute phase

Road safety
Observe the following notes about road safety:

To avoid any injury or damage to yourself, your car and others, please make sure to do as following. Observe the following note to protect yourself against injuries:

- Before using this unit, please read all related instructions carefully.

- Any damage to this unit caused by improper operations will void the warranty.

- Please do not watch videos or use other Apps while the vehicle is in motion. Doing so, is a Safety violation. To watch videos or use Apps, please ensure that the vehicle is in parked mode with handbrake activated.

- The below-listed applications while driving the vehicle may divert your attention form the traffic situation and may lead to serious accidents:
  - o Using the navigation feature like entering the destination address
  - o Video playback or watching any kind of video
  - o Usage of internet via the browser
  - o Use of connected phone via PhoneLINK
  - o Use or Download of Google PlayStore / Google Maps / YouTube is not permitted in the automotive environment

- You are advised to refrain from any activity which could possibly divert your attention while driving. The best way to use these applications is when your vehicle is parked in a safe location.

- To avoid short circuit, please do not dispose the unit into the water and please do not place or leave any kind of metal object (such as a coin or metal tools) in the unit.

- Please operate the unit as per this Manual, it is not allowed to open the unit for maintenance; In case if maintenance is required, please seek professional help.

- After the car engine is off, please do not use the car audio for a long time, otherwise, the battery could be drained.

Instructions to read this User Manual

Illustrations are used in this manual to explain operations and precautions. The illustrations used in this manual are only for reference, please take the actual unit as standard.

Marks

⚠️ Mark for important preventive measures; please read carefully to prevent any injury.

🗨️ Mark for a special explanation, auxiliary interpretation, imitation and references.

📋 Mark for additional information to operate this unit. Warm notes: When there is any difference between the Manual and the actual unit, please take the actual units as standard.

Declaration of conformity

We declares that the device complies with the basic requirements and the other relevant regulations of the RED Directive 2014/53/EU.

Cleaning notes

- Solvents, cleaning and scouring agents as well as dashboard spray and plastics care products may contain ingredients that will damage the surface & screen of the audio system.

- Use only a dry or slightly moistened cloth for cleaning the audio system.

Disposal notes

- Do not dispose of your old unit/batteries in the household trash.
- Use the return and collection systems available to dispose of the old device.

Scope of delivery

The scope of delivery includes:

- Car audio system
- GPS antenna
- External Bluetooth microphone
- Small parts set, installation material
- Screws and fasteners
- Connecting cables

Home Menu

1. CarPlay - Connect to iPhone
2. AUX - IN - Listen to an External audio source
3. BT Music - Stream audio via BT
4. Android Auto - Connect to Android phone
5. USB - Play music/video via USB flash drive
6. Radio - Listen to FM / AM radio stations
7. Phone - Hands-free Calling – Call and Receive via BT
8. Settings - Setup preferred parameters of the device

9. Screen off - Turn OFF screen display
10. Clock - Time clock display
11. EQ - Choose different preset EQ options
12. Steering wheel control

Radio

Switch between FM/AM
Touch (FM) to switch between FM and AM tuner modes

Automatic Search and Storage Station
Touch (🔍) to automatically search and save stations. When search is completed, the first radio station is automatically played and the radio list is displayed;

Play Preset Station
Touch (Radio), (FM FM) or (AM AM) select the station in the list to play.

Manually Search Station
1. Touch or hold (◀) or (▶) to automatically search the radio station. If the desired station is displayed, the process will stop and play the current station, and then touch the button to search again;

2. If there is no preset station, the finger swipe left or right at the bottom of the screen to search the desired radio station. If the desired station is displayed, the process will stop and will play the selected station and then swipe to search again.

Switch Station
1. While playing a preset station, touch (◀) (▶) to switch to the previous or next station;

2. While playing preset station, the finger swipe left or right at the bottom of the screen to switch to the previous or next station.

3. Touch (◀) or (▶) to fine adjust radio frequency;

4. Sliding (▦) left or right to rough adjust radio frequency;

Save Station

1. Touch the upper half part of the now playing station, it will display some of the saved stations; Touch (♡) to save current station, touch (87.50) to play the station;

2. Touch (Radio) then (♡) in FM or AM list to save station;

3. When (♡) changes color, touch it again and it will remove the station from the saved list

4. Touch (Radio) (Favorite), then touch (🗑) to cancel saved stations

5. Touch and hold (87.50) to cancel save function

Media Player

Insert USB Flash Drive with media files into the USB slot

Supporting Format
1. Music: APE, FLAC, MP3, WMA, WAV, M4A, OGG ,etc.;

2. Video: 3GP, AVI, MKV, MOV, MP4, MPEG,,VOB, WMV, M4V,etc.;

3. Picture: JPG, PNG, BMP;

Play Music

Touch (▣), select (▣) to show the music list. Slide up and down the list and touch the selected song to play and adjust the play progress in the progress bar; Touch (▣ Playing) to return to the player interface;

Play Video

Touch (▣) select (▣) to show the video list. Slide up & down the list, touch the selected video to play. Touch the screen to exit full screen mode;

View Picture

When playing music or video, touch (▣) , then touch (▣) to show the list of pictures. Slide up and down the list, touch the selected picture to view; Touch (▣)or (▣)to view previous or next picture; Touch (▣)to return to the list.

Play Folder Contents

While playing music or video, touch (▣ Playing),then touch to switch to folder mode, and it will exit the mode if user touches it again;

First Letter Search

Touch (▣) or touch the circle while using the progress bar to fast search a file by the first letter;

Switch Tracks

Touch (▣)or (▣), to switch to previous or next track finger swipe left/right on the play interface to switch to previous or next track.

Download Phone Book

touch (Download)to download phone book from mobile device, at this time it will show the download tips on the screen of mobile device, touch YES for download, touch NO to not download.

Incoming call / Outgoing Call

1. Dial the phone number to call on the touchpad of the device
2. Select a name from the phone book to call
3. Choose a record in the call history to call
4. When there is an in coming call, there is an option to either accept or reject the call

Hands-free Mode and Private Mode

During a call, touch (▣) & (▣) to switch between Hands-free mode and private mode; Touch (▣) to mute microphone so that the receiver cannot hear from your side.

Delete a paired device

1. Touch the connected device name to Delete
2. Touch the Trash icon next to the device name to delete;
3. Delete device from the connected devices list directly on the mobile device;

Bluetooth Audio Music

The product supports A2DP, AVRCP, PBAP and HFP protocol; Make sure Bluetooth device volume on the mobile device is turned to max.

Switch Tracks

1. Touch (◁) or (▷) to switch to previous or next track
2. Finger swipe left/right on the play interface to switch to previous or next track

Play/Pause

Touch (▷) to play, touch (▯) to pause or play on the connected BT device

Play/Pause
Touch (▶) to play, touch (❚❚) to pause

Playing Modes
(⬄)Sequential playing mode
(⬄)Single cycle mode
(⬄)Random off

Bluetooth

Bluetooth connection is not available when Apple CarPlay is on.

Search Bluetooth Device
Please make sure that the device you desire to connect to has been turned on and allowed to be detected; Use a mobile device to search for the device, the name B910AU - San Andreas 970 (SA970) will be displayed on your mobile device;
or touch (Search)to search the surrounding Bluetooth devices. All the devices available will be displayed on the screen.

Bluetooth Pairing
In the mobile device, touch name of the device or choose mobile device on the screen to connect, and then wait for the connection.

Automatic Connection
If the connected device is out of the operating range, the Bluetooth connection will be disconnected automatically. If user does not close the Bluetooth function, the Bluetooth is automatically reconnected when the device returns to within the operating range.

CarPlay
(Supports Wireless CarPlay)

Please use an Apple Lightning cable to connect an iPhone with the device & it will automatically light up the CarPlay icon on the screen; Touch the CarPlay icon and all the CarPlay allowed apps are displayed on the screen. These apps are the one's most used while traveling and cause the least amount of distraction while driving.

iPhone support: minimum requirement: iPhone5; Required iOS: minimum iOS 7.1.

Make a call / Receive a Call
Touch the main interface of CarPlay mode to make a call or while receiving a call

Play Music
Touch the main interface of CarPlay mode to access all of your content from iTunes or Apple Music

Use Maps
Touch the main interface of CarPlay mode to let the iPhone help you Navigate

Check Messages
Touch the main interface of CarPlay mode to send a message or check unread message;

Siri
1. Touch and hold Apple Home key on device or iPhone to use Siri voice assistant, such as making a call, playing music, open the map function and other voice commands;

2. Touch the Voice key on the front panel

3. When iPhone is connected, access Siri from the steering wheel control (some cars)

4. Control with "Hey, Siri"

Android Auto
(Supports Wireless Android auto) (Most Phones)

Connect Android phone to the device with a standard micro USB cable to access music from their phone, navigate with Google Maps & make or receive calls It is recommended that the device and mobile phone be paired via BT initially.

Min required Android OS: 5.0. (Android Auto App must be installed on the mobile phone before connecting)


( ) Open map;
( ) Open dialer;
( ) Now card screen, tap cards to go to music player or map, and also make a call directly;
( ) Open or choose music App;
( ) Choose to return to native screen;
( ) Push to talk(Enable voice assistant)

AUX
Connect an external audio source using a 3.5mm stereo AUX cable.

Settings
General Settings

1. Touch to select the time zone in the region the device is being used in
2. Touch to set date, touch OK once settings are done
3. Select option for 24H mode;
4. Select Auto Adjust mode to automatically allow device to set time using GPS provided information Select Auto Launch for Android Auto (Android auto projection mode is active)
5. Enter advance settings

6. Select Rear View Camera Delay mode
7. Select option to delay device Turn OFF in case of connecting an external amplifier
8. Touch to restore to factory settings

Advance settings
Enter password 0000

1. Steering wheel control
2. Select to Turn ON / OFF reverse camera dynamic guide lines
3. Select to Turn ON / OFF Screenshot capability
4. Touch to select reverse camera Static Trajectory Adjust settings
5. Touch to select left or right driving position (for CarPlay), reconnect to allow device to recognize new selection
6. Touch to select Front Panel light color
7. Touch to adjust brightness of Front Panel light color

Steering Wheel key

when the (SWC) s selected, Touch the required icons to set corresponding to the number of buttons available on the Steering wheel. Press one steering wheel key and the screen will show a window with a message **"Press the physical key on the steering wheel"**, the key will save the function of the button after it is selected on the steering wheel (confirm) with the item displaying (Activated)(repeat all wanted items before confirm). One key has just a function after setting for once. Touch (Calibrate) to recalibrate the key.

Audio Settings

1. Select beep, one touch one beep
2. Select to Turn ON / OFF loudness effect;
3. Control subwoofer level
4. Adjust the volume of each source

5. Select the desired sound effect from the options at the bottom of the screen
6. Move original point to adjust the speaker output balance

Display Settings

1. Adjust screen brightness (when vehicle headlights are on)
2. Restore to default settings

Bluetooth Settings and Device

1. Turn ON / OFF Bluetooth
2. Turn ON / OFF Automatic Connect
3. Turn ON / OFF Automatic Answer incoming calls
4. Turn ON / OFF Automatic download phonebook; if ON, the device will automatically download phonebook

Apple Carplay Device

1. Open IPhone bluetooth and click the search that will display device and wireless carplay will be connect when click the device.

Android Device

1. Open iPhone Bluetooth and select search, this will display a list of available devices and select the B910AU - San Andreas 970 to pair and wireless CarPlay will be connected

Rest WIFI Password
1. Click reset WiFi paasword and the unit WiFi
password will be rest.

Change device name
1. Touch to modify the device name;

Radio Settings

General	Seek Quality	
Audio	FM	0
Display	AM	0
Device	Reset Seek Quality	
Radio	Region	Asia
About	RDS	
Home	AF	
	TA	

1. To decrease the sensitivity of the scan feature of the
radio tuner slide to the left and to the right to increase
the sensitivity of the tuner
2. Touch to restore to default sensitivity
3. Touch to select the region, please do not change the
region settings arbitrarily
4. Turn ON / OFF RDS function

Additionally: Drag up on radio screen to check device
version

Useful information

Warranty

We provide a 2 year manufacturer's warranty for
products bought within the India. For devices
purchased outside the India, the warranty terms issued
by our respective responsible domestic agency is valid.

Register **ONLINE** within **15 days** of **PURCHASE** to
activate **WARRANTY.**

The procedure to activate the warranty is given below;

● BLAUPUNKT

INSTRUCTION CARD
for Warranty Registration.

Please activate your **2 Year** warranty within
15 days of purchase. Warranty can not be claimed if not
registered online within **15 days from the date of purchase**.
To activate your e-warranty, please follow below guide

Step 1. Please SMS <**serial number**> to **07760962759**

Step 2. In response to the sent SMS, you should
receive back a link via SMS, please **Click** on it

Step 3. Complete a simple form to register
your product & activate e-warranty.

E-user manual is available at www.blaupunktcar.in
and upon completion of registration.

Should you require further assistance,
please call: Customer Support 1800 209 6820 OR
Email us: info@blaupunktcar.in

Note: WARRANTY not applicable if bought from third party online portals.

Service

If your device should need service or to get more
information about our local authorised service center,
you can email us at
Email: **Support@blaupunktcar.in**
OR
Call **1800 209 6820**

Should the device malfunction for any reason, please follow below recommended guidelines

1. Restore to factory settings or Hard Reset device
2. Try Restarting the device
3. Please check the below list of common that are described in the table below and try to use the solutions;
4. Contact Service Center;

Video Files		
Machine / Function	**Phenomena**	**Solutions**
Machine	Cannot power on/off	Check the connection, if it is broken, try to reconnect it; Check the main fuse, if it is damaged, replace it; Press reset key;
	No sound	Adjust the volume; Confirm whether the music and video is supported or not; Confirm whether the connection of the power amplifier is lost;
Reversing	Abnormal picture	Exit reversing mode and enter again; Check whether the camera is covered by foreign matters; Check whether the type of reverse camera is matched or not; Check the reversing signal cable;
Radio	Noisy; Cannot search the station	Ensure there is no metal products around the machine; Driving the vehicle to the place where the radio signal is good and search the station; If the solutions above are invalid, please check whether the antenna is disconnected, damaged, etc.;
Bluetooth	Connecting fail	Please make sure that the Bluetooth of mobile device is turned on, the machine is not connected
USB playing	Playing fail	Ensure the U disk is not damaged; Please make sure that the format of content is supported;

CE