


Panel



Home Menu



Radio



Music Playback



Video Playback



Photo Playback



Bluetooth



PhoneLINK



AV In



Sound Effect



File Manager



Theme




Camera



CANBUS



Settings



Installtion



Carplay




Android Auto



TPMS

The head unit features a brilliant capacitive display with a high-end tuner



1. Internal microphone
2. Reset button. System reset
3. Power/Mute button
Short Press: Turn on device, Mute Audio;
Long Press: Device Power OFF;
4. Home button. Go to home menu
5. Back button. Back to previous menu
6. Volume increase
Short Press: Increase volume in single step;
Long Press: Volume Up;
7. Volume decrease
Short Press: Decrease volume in single step;
Long Press: Volume decrease;

More ways change Volume:

1. Drag left and right on volume control bar;
2. Touch bottom right side to display system menu, Drag up and down Media bar;
3. Short or Long press SWC Volume+ / Volume- button;



Keep pressing touch screen more than 5 seconds with 5 fingers will start to calibrate and reset side buttons.





1. Enter Music playback menu
2. Enter Bluetooth Music playback menu
3. Enter Video playback menu
4. Enter Sound Effect settings menu
5. Enter File Manager menu
6. Enter Photo playback menu
7. Enter System Control menu for quick access to system Settings including Brightness, Volume, Bluetooth, Wi-Fi NO/OFF, Mute, Screen Off, System Reboot, Turn On screen saver, Night Mode ON/OFF, take Screenshot
8. Enter PhoneLINK menu
9. Enter System Settings menu
10. Drag left or right on screen for previous/next page
11. Enter Bluetooth menu
12. Enter Radio menu




1. Enter CANBUS settings menu
This setting is only to be used at the time of installation of device. Incorrect settings may cause some functions to not work. Please seek assistance from the Technical Service team if necessary
2. Turn OFF screen, Device continues to work in the background
3. Check GPS signal status
4. Enter AUX-IN menu
5. Enter AndroidAuto menu
6. Enter Carplay menu
7. Enter TPMS menu. This function is Optional, may not including on device
TPMS works with module and sensors, if installed. This function will not work if the module is disconnected
8. Enter E-Manual
9. Media playback shortcut. Access last Source menu
10. Enter Theme menu
11. Navigation shortcut: It will not work if there's no MAP application installed
12. Enter Bluetooth menu
13. Enter Camera menu
14. Back to previous menu
15. Back to Home menu



1. Enter radio settings menu
2. Enter radio source menu
3. Enter radio playing menu
4. Enter equalizer menu
5. Input frequency by manual
6. Save or delete the current frequency to favorites list
7. Auto store. Click this icon will start scan and save value stations into seek list
8. Frequency bar, drag left or right can change radio frequency
This bar will not have when playing favorites or searched stations list
9. Next key and [11] Previous key
On tune playing menu, this key for search and stop to play next value station;
On Favorites and Search playing menu, this key for next station;
10. Play/Mute radio
12. Tune menu, select FM or AM system will go into playing menu






1. Enter favorites list. Select station to enter playing menu
On this playing menu Next/Previous button and SWC button only for Next/Previous station, can not support frequency scan;
2. Delete station from favorites list
3. Enter Search menu
4. Select band
5. RDS PTY filter settings
6. Start to search and save value stations to search list
Click station to go into playing menu;
On this playing menu Next/Previous button and SWC button only for Next/Previous station, can not support frequency scan;



1. RDS AF On/Off. AF on, radio will change to other better signal frequency automatically for better receive
This function just works on the radio broadcasting support AF function, others will not change frequency;
2. RDS On/Off
3. Radio sensitivity setting

1. Enter music file Library menu
2. Enter Playing menu
3. Enter Equalizer settings menu
4. Setting Repeat current playlist, Repeat One, Shuffle playback.
5. Show playing list
6. Drag this bar change Elapsed time
7. Next Track
8. Play/Pause
9. Previous Track
10. Play Music File






1. Start to play this file
2. Play this file next
3. Play this file at end of PlayList
4. Add this file to specified list
5. Delete this file from storage



1. Back to video file list
2. To delete video file or check file information: touch the video file for 2 seconds and it will pop out from the File Management menu to either delete or check file information. A file once deleted cannot be restored.
3. Drag left or right on this bar or progress bar to move withing the file
4. Setting display ratio: 1:1, 16:9, 4:3, Full screen, Auto
5. Play mode: Play once, Repeat current file, Repeat all
6. Next
7. Play/Pause
8. Previous
9. Scan and update all video files
10. Change File-Sort, Manage Files, set up File list display mode and enter PlayBack settings
11. Play this file
12. Video File folder path
13. Video Library



14. Setting for Video PlayBack:

Resume Play-Yes: Start PlayBack from last stopped point

Resume Play-No: Start PlayBack from beginning

Check at Start-Up: Show selection menu

15. Play in background:



ON: Video continues to play in the background;

OFF: Video stops playing once application has been moved to the background


16. 360 display:

ON: 360 AVM recorded video files can be played


OFF: 360 AVM recorded video files will not be played




1. Photo file list
2. Slideshow: Each photo is displayed for 3 seconds as a Slideshow
Delete: Delete Photo file from storage
Crop: Edit photo
Rotate: Rotate display Photo
Set as Wallpaper: Set current photo as system Wallpaper
 A file can not be restored once deleted
3. Scan and update Photo files
4. Files Management
5. Display this photo
6. Photo files Folder path
7. Photo files Library






1. Favorite contacts
2. Phone Book
3. Call History
4. Keyboard
5. Input Number
6. Numeric Keypad
7. Delete Input
8. Contacts. Touch a contact on screen to dial out
9. Dial out/Confirm input number
10. Call history. Click [∇] to display Call History or Display Missed Call list
11. Update Call History from mobile phone
12. Click Contacts List for dialled numbers
13. Click [☆] Add Contact to Favorites list






1. Search Contact-letters or numbers
2. Download Phone Book
3. Touch right side letters to display priority contacts or matched contacts
4. Touch contact to dial out or add to Favorites





1. Cancel dialing / Reject incoming call
2. Mute microphone during a conversation
3. Display numeric keypad for additional input
4. Transfer phone call between car infotainment and mobile phone
5. Click favorites to Dial out or delete it from favorites list
 - A. This radio has 96 different ringtones integrated into it, user can select favorite one for incoming calls;
 - B. Phone call volume and Ringtong volume can be increased separate in the system -- Go to [Settings] -- [Volume] -- [Phone volume] and [Ring volume];
 - C. This device by default works with an external microphone. It can be changed to internal microphone. To switch to internal microphone go to [Settings] -- [Volume] -- [Microphone];





Select [BT Music] on home menu to active BT streaming

1. Previous
2. Play/Pause
3. Next
4. Enter Equalizer setting




1. Scan QR code for download and install EasyConnect application in the mobile phone
2. Share Hotspot from mobile phone to the device
3. Click PhoneLINK on the home menu to connect mobile phone to the device
4. Connect mobile phone with USB cable and open the app
5. Enjoy PhonLINK







1. Touch [AV-IN] on the HOME menu to start AUX-IN playback
2. For Audio connect a Stereo 3.5mm cable to the Input port, For Video input, connect via the RCA ports provided in the rear of the radio
3. Audio and video quality depends on the source, It's recommended to input high quality video and audio for best results




ASP sound effect settings:





1. Enter Additional Settings menu
2. Enter Equalizer setting menu
3. Equalizer pre-sets
4. Enter individual frequencies setting menu
5. Reset all items of this menu to default settings
6. Individual Frequency Setting status
7. Change each individual frequency gain levels:
Select a frequency - Press [7] horizontal arrows to increase or decrease the level of the selected frequency;






1. Subwoofer ON/OFF
2. Loudness On, all channel outputs are enhanced
3. Enter Subwoofer Filter settings
4. Enter BAL/FAD setting
5. Reset Subwoofer Filter to Factory default
6. Filter ON/OFF
7. Filter settings status display
8. Subwoofer Gain adjust
9. Frequency setting
10. Subwoofer Phase setting







1. Adjust Balance/Fader with single step
2. Drag the point adjust BAL/FAD
3. Reset BAL/FAD to Factory default





1. Enter category menu
2. Enter Storage Browse menu
3. Enter Storage File path menu
4. Files Categorized - classify Files as Images, Videos, Audio, APKs and Update file FUPs. Recently visited files under recent File manager application works for File Cut/Copy and Paste, Rename, Create folder and similar





1. Enter Wall paper list
2. Enter Theme list
3. Preview Integrated Themes
4. Integrated wallpaper preview
Select favorite Theme or Wallpaper - Touch Apply on pop-up menu, the Theme and Wallpaper will change to the selected option







CVBS Camera and 4 Channel AHD Camera Reverse Input Settings:

Touch Camera option to access the Reverse Camera input menu, then press the top right corner to display the pop-up Settings menu;

1. Select one camera input to change settings
CVBS and 360AVM mode does not have this option;
2. Camera Input video display settings
3. Reverse track settings
4. Original Proximity Radar display





360 AVM Camera Settings:

360AVM function is optional, the device may not including

Go to [Settings]--[Reverse mode]--[Reverse video input]

--Select 360AVM pro to active 360AVM function

Set up the camera Format to match Cameras for camera video display

1. See around view video

2. Touch for take a picture


The device must have storage device on USB port with correct Record Device setting

3. Car model shop

4. Settings

5. Carmodel setting

6. Calibration and Bird View settings. These settings only for installation






Carplay:

1. Device list
2. Carplay connect and display settings
3. Touch Paired device to connect
4. Scan available devices
5. Turn carplay ON/OFF
6. Set up device discoverable for iPhone
Paired iPhone can connect to device only [5], [6] ON
7. Right Side driver use

Android Auto:

Similar setting as Carplay







Touch [Settings] on HOME page or Touch right bottom bar, then Select the [settings] icon on pop-up menu to access displayed options

Settings menu:

Incorrect setting may cause the system to malfunction. Please Select [Factory reset] to revert to default Factory settings or consult with the Service Department

Display Settings:

1. Enter MiraVision display setting menu
2. Adjust overall screen Brightness setting
3. Night mode On-Screen and Backlight to change Brightness
4. Headlight/Parking lights ON: The overall screen and keys illumination level will decrease to 50%, provided the Illumination lead is connected to the factory harness.
Sync with Internal System Clock: Once the Night mode is turned ON, the screen brightness will drop in Sync with the time of day
5. Parking ON - Playback of moving images or videos is blocked until the parking brake is activated. It's required to connect the Parking Brake wire to the Handbrake switch
6. Screen Saver ON - Clock display after [7] pre-set Interval duration.



To go back to Main screen, touch any key or the screen to exit Screen Saver mode

7. Interval Duration - to start Screen Saver

8. Wallpaper settings

MiraVision display settings:

9. Default is Standard Mode.

Select Active User Mode for below additional Settings

10. Drag bottom dot sideways to change Contrast

11. Drag bottom dot to change Saturation

12. Drag bottom dot to change Picture Brightness

13. Drag bottom dot to change Sharpness


14. Drag bottom dot to change Color Temperature

15. Switch On Dynamic Contrast for HDR

16. Switch On BluLight Defender and drag bottom dot to change the BluLight effect.

Any changes to these Settings can be seen immediately

17. Restore default settings



Bluetooth Settings:

1. Change Device Name
2. Manage device - System can connect with multiple Bluetooth devices, and each device function can be set up
3. This device works with A2DP audio streaming
4. This device works with HFP-handsfree phone calls


Bluetooth Pair and connect:


Search for available Bluetooth devices

Select an available device and Press pair to show a pop-up menu.

Touch [Pair] on both devices

System will search and Connect with the last device automatically upon boot up





Wi-Fi Setting:


Select one of the available networks, input Password in the pop-up menu to connect to the available Wi-Fi network.


Ensure the Wi-Fi/Bluetooth antenna has been connected to device

Source Volume Settings:


Individual Source volume levels can be set up for overall sound output balance while switching sources


1. Navigation volume setting
2. Media playback volume setting
3. Phone call volume setting






4. Incoming phone call ring volume setting
5. Voice assist volume: Application for devices equipped with Voice Assist
6. System Volume Level at Start: Can be set to a range from 4-12 as Start - Immaterial of what the last volume level was, it will default to a level selected between 4-12
7. Navigation alert mix level: To reduce or increase the individual Source Level when there's a prompt from the Navigation source
8. Microphone gain setting
9. Touch Beep tone
10. Microphone external / internal setting
11. Incoming phone call ringtone setting
12. Adjust Volume level when reverse gear is selected







Application Settings:

1. Auto Restart modes: Disable Auto-start: System will stay on Homepage upon Start
2. Last opened Media app: System will open last Media app and commence playback
Specific app: System will open specific app on [2] automatically
It is an extension of [1]
3. Specify default app from similar multiple apps: This option will not work if the device has only one app






Reverse mode Setting:


Incorrect setting may cause video to not be displayed on the screen. Please check camera specifications and select correctly from options given. Incorrect selection may cause issues with the video signal display on the device


1. Reverse camera CVBS input: Reverse camera format must be CVBS format
2. 360AVM: Reverse cameras format setting must match installed cameras, Device supports 720P and 1080P camera video input
3. 4 channel AHD camera: [2], [3] settings must match installed cameras
4. Cameras format setting 360AVM and 4 channel AHD camera format settings, This setting is for compatible right side CVBS camera 4, 5, 6. Front, Left and Right side cameras can be Off
7. Delay Reverse Display setting: Duration of reverse camera view display after reverse gear is disengaged
8. Delay quit time setting
9. Auto Front Camera display once Reverse gear is disengaged



Display Key Illumination Setting:

1. Key Illumination mode setting
Always ON: System ON, Display backlight ON
Vehicle Illumination mode: Display backlight ON only when headlight is ON
2. Enter key light color setting menu
3. Dynamically change colors On, panel light changing multi color automatically
4. Select color tile or on color circle, then click [Apply]







Time and Date Setting:

1. Display Date OFF - the bottom bar will not display Date information
2. Display Week OFF - the bottom bar will not display Week information


SWC Setting:


3. Enable SWC function
4. Enter SWC button pair menu
5. Enter SWC button function diagnosis





1. Select a function key, then select short press or long press and then press same function button on the steering wheel control. Press 3 times to ensure pairing success
2. Click Clear to erase paired button: Ensure AD Key1/ Key2 wires are connected to the vehicles wiring harness correctly. Should the SWC button not work as expected, follow the pop-up menu and check the connections






System Settings:

1. Reboot system: OS and applications will reboot
2. Factory reset, will erase all user data and return to Factory Default settings

Ensure user data is backed up before Factory Reset.

User data cannot be recovered after a Factory Reset;

3. System update only works on value update file
4. Key system connect to network and download newer version software and update automatically





Installation:

4. Power interface
5. Multifunction Interface
6. GPS antenna
7. FM/AM antenna
8. 5G Wi-Fi antenna


No all models come with functions listed above.

Depending on the features included the User Interface may vary.




Multifunction Interface

1	3	5	7	9	11	13	15	17	19		1	3	5	7	9	11
AMP	AUX_Input_R	AUX_Input_L	SIM_DATA	SIM_DET	SIM_CLK	SIM_RST	SIM_VDD	Front CAM/ Right CAM	MIC-		Left_Turn_Det	AHD GND	AHD GND	AHD GND	AHD GND	Camera Power 5V
GND	Audio_Out_FL	Audio_Out_FR	GND	SIM_GND	GND	NC	SUB_L	AUX_Input_V	MIC+		Right_Turn_Det	Front AHD	Right AHD	Back AHD	Left AHD	Camera Power 5V
2	4	6	8	10	12	14	16	18	20		2	4	6	8	10	12
1	3	5	7		1	3		1	3	5		1	3	5	7	9
GND	Audio_Out RL	SPDIF Power	CAN-RX		USB_5V	USB_GND		USB_5V	USB_GND	NC		UART_TX	UART_RX	IR Out	Reverse CAM Power +12V	PARKING
SUB_R	Audio_Out RR	SPDIF Out	CAN-TX		USB0_OTG_DP	USB0_OTG_DM		USB1_DP	USB1_DM	NC		2.4G Wifi/BT_Ant	RCA_GND	Reverse Camera	CAMERA_GND	5G Wifi/BT_Ant
2	4	6	8		2	4		2	4	6		2	4	6	8	10



1	3	5	7	9	11	13	15
GND	ACC	Reverse	SWC Key-1	FR-	FR+	FL-	FL+
B+	ILL	SWC Key-2	Ant. Power	RL-	RL+	RR+	RR-
2	4	6	8	10	12	14	16

Power Interface



TPMS:

This function is Optional, may not including on device

TPMS works with module and sensors, if installed. This function will not work if the module is disconnected